

## Texas Chainsaw Massacre Coil Chart

Red Chain			Green Chain			Blue Chair		
Wire	Coil	MOSFET #	Wire	Coil	MOSFET #	Wire	Coil	MOSFET #
0 Purple	Sling Left	<b>Q8</b>	8 Purple	Lower Right Flipper Main	<b>Q9</b>	16 Purple	Upper Left Flipper Main	<b>Q10</b>
1 White	Lower Left Flipper Main	<b>Q29</b>	9 White	Auto Launch	<b>Q30</b>	17 White	Magnet	<b>Q31</b>
2 Black	Lower Left Flipper Hold	<b>Q11</b>	10 Black	Lower Right Flipper Hold	<b>Q12</b>	18 Black	Upper Right Flipper hold	<b>Q13</b>
3 Yellow	Drop Target Knockdown	<b>Q26</b>	11 Yellow	Knocker	<b>Q27</b>	19 Yellow	VUK	<b>Q28</b>
4 Brown	Divertor (Ball Lock)	<b>Q14</b>	12 Brown	Trough Eject	<b>Q15</b>	20 Brown	Upper Right Flipper Main	<b>Q16</b>
5 Orange	Front Scoop	<b>Q23</b>	13 Orange	Right Sling	<b>Q24</b>	21 Orange	Back Scoop (Door)	<b>Q25</b>
6 Pink	Drop Target Reset	<b>Q17</b>	14 Pink	Shaker	<b>Q18</b>	22 Pink	Right Divertor	<b>Q19</b>
7 Grey	Center Scoop (Left Orbit)	<b>Q20</b>	15 Grey	Right Up Post	<b>Q21</b>	23 Grey	Upper Left Flipper Hold	<b>Q22</b>

**Note:** Ensure safety precautions are taken, and the machine is disconnected from power during this process. Seek professional assistance if you are not comfortable or experienced in working with electronic components.

**NOTICE**

Need to report a code bug in Texas Chainsaw Massacre? You can send an email directly to [DJ@spookyinball.com](mailto:DJ@spookyinball.com) with the subject "Code Bug"